




Adding a device in Insight RS

At the Insight RS Hosting Device, Click on **Add Device**



Add a Device

You can discover a single device without the need to update your discovery settings in the Administrator Settings menu. When discovering a single device, Insight RS uses the protocol credentials that you have configured on the **Discovery** → **Credentials** tab. If the correct protocol credential is not assigned to the device, you can modify the assignment in the **Device Details** → **Credentials** tab.

Enable Devices for Insight Remote Support

When a device is enabled for Insight Remote Support, monitoring and collections take place.

To enable a device for Insight Remote Support, complete the following steps:

1. In the main menu, select **Devices**.
2. Click the **Device Summary** tab.
3. Select the check box in the far left column for the devices you want to enable.
4. Click **Actions** → **Enable Selected**.

© Copyright 2015 Hewlett Packard Enterprise Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for Hewlett Packard Enterprise products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Hewlett Packard Enterprise shall not be liable for technical or editorial errors or omissions contained herein.